



Wall mounting a battery conditioner

The general principle is to mount the unit in a safe, ventilated place where any heat that might be generated in or around a conditioner can be dissipated. Peter Spurrs feels a wall mounting is the obvious place. Soft and flammable surfaces are to be avoided. Some users secure the unit in a wooden or metal box which can also be wall mounted.

CTEK wall mounting

CTEK offer a neat wall mounting bracket and the conditioner clips neatly into the bracket. The bracket holds your MXS charger securely and has a practical hook to keep your charger cables stored neatly. Mounted at eye level, the various lights on the CTEK conditioner are easily seen so the current state of the device can be followed. [See CTEK webpage](#)



Accumate wall mounting

Dugald MacNeill has had his Accumate conditioner since 2017 and has it mounted on the garage wall using the Accumate wall

mounting bracket (part number: **TM75**) with the charging lead from the conditioner draped over the passenger window into the car to plug into the cigar lighter socket. The socket is permanently live and is a very convenient place to connect the conditioner. The plug has a small neon red light showing when it is live in the socket.

Wall mounting the Accumate with the plastic bracket provides a convenient way of locating the conditioner and as an alternative the bracket can be located to hang over the top edge of the side window glass.



Wall mounted bracket



Bracket on the side window

On visiting the Accumate website it appears the wall mounting bracket is now a "[discontinued product](#)" however Peter Spurrs has found another [website](#) which seems to offer plastic wall brackets.



See Accumate's fitting instructions for the wall bracket. [More](#) & [More](#) plus [guidance leaflet](#) on using the conditioner